



Concealed Shower Set Installation


INSTALLATION MANUAL Tools You Will Need :




Adjustable wrench



Hexagon wrench



Phillips Screwdriver




Pipe Tape


Notes before installation :

1. Please check that all components are present.
2. Before installation ensure that all feed lines are clear of debris and on/off valve is present.
3. Ensure water pressure is between 20-125 PSI (includes combination of hot and cold feed lines).
4. Pictures in the manual are general in content and may not represent exactly your purchased faucet.
5. If you are having difficulties please contact a professional plumber.
5. If you will be away from home for an extended period you should shut off the main water supply.


⚠ All valves pass air and water testing during manufacture. If request air test before installation, MUST under the guide of professional plumber, and air pressure DO NOT over 145PSI (=10KG).




1. Confirm the installed place of the pressure balance valve and fixed on the wood block .




2. Connect the hot&cold inlet tube and outlet tube, then make sure the tube fix stable on the wooden wall.



3. Lock the deck plate into the body and celling to the wall.



4. Install the handles by hexagonal wrench, then install the red and blue color button.



5. Install the shower arm, shower head and flange to the fitting. (stick to the wall) . Tighten the showerhead to the shower arm with the pipe tape. (Make sure the pipe tape with clockwise direction) .