

INSTALLATION INSTRUCTIONS **MODERN 4/6L ONE PIECE TOILET**

Model TT-0382Z-MB

Complies with ASME
A112.19.2/CSA B125.1-2013.

Please check the condition of the product before installation. By choosing to install the product, the customer accepts the condition of the product.



⚠ CAUTION: PRODUCT IS FRAGILE. TO AVOID BREAKAGE AND POSSIBLE INJURY HANDLE WITH CARE!

RECOMMENDED TOOLS AND MATERIALS

Putty Knife	Regular Screwdriver	Adjustable Wrench	Sealant	Measuring Tape
Hacksaw	Wax Ring/Gasket	Flexible Supply Tube	Closet Bolts	Carpenters Level

1 REMOVE OLD TOILET (IF NEW INSTALLATION, PROCEED TO STEP 2)

- Close toilet supply valve and flush tank completely. Towel or sponge remaining water from tank and bowl.
 - Disconnect and remove supply line. **NOTE: If replacing valve, first shut off main water supply!**
 - Remove old mounting hardware, remove toilet and plug floor waste opening to prevent escaping sewer gases.
 - Remove closet bolts from flange and clean away old wax, putty, etc. from base area.
- NOTE: Mounting surface must be clean and level *before* new toilet is installed!**

