

Towel Rail Installation

- Read the instruction sheet carefully before installation.
- Installation should be completed by a professional electrician.
- Please dispose the package properly.

tools required




Screwdriver



Pencil



Spirit Level




Rubber Hammer




Tape Measure




Gloves






Drill Bit




Electric Drill




	Round tube support tube	X 3
	Surface-mounted circular support tube (with wire-passing notch)	X 1
	New expansion tube	X 4
	Expansion screw	X 4
	Mounting base	X 4
	Phillips pan head screw	X 3
	Cone point set screw	X 5
	Allen wrench	X 1




step 1
Please confirm the installation location before installation




step 2
Fix the three round tube support tubes to the nut posts on the back of the towel rack with cross pan head screws M6*12. Put a surface-mounted circular support tube with a wire-passing notch into the nut column at the position of the power wire, and fix the set screw M5x6 with the tapered end with an inner hexagonal wrench.




step 3
Place the towel rack on the wall to be installed, and mark the location of the wall bracket screws with a pencil.



step 4
Use an 8MM drill bit to drill holes at the marked locations.



step 5
Knock the expansion tube into the drilled 8MM hole, and fix the installation base $\varnothing 18 \times 18$ on the wall with expansion screws.










step 6
Assemble the towel rack to the mounting base on the wall, screw the tapered set screw into the screw hole of the round tube support tube with an Allen wrench and tighten it.

Towel Rail Installation

- Read the instruction sheet carefully before installation.
- Installation should be completed by a professional electrician.
- Please dispose the package properly.

tools required





X 1




X 1

Concealed round support


	Round tube support tube	X 3
	New expansion tube	X 3
	Expansion screw	X 3
	Mounting base	X 3
	Phillips pan head screw	X 3
	Cross recessed countersunk head tapping screw	X 2
	Cone point set screw	X 5
	Allen wrench	X 1




step 1
Please confirm the installation location before installation.




step 2
Fix the three round tube support tubes to the nut post on the back of the towel rack where the plug has been cut off with the Phillips pan head screw M6*12. Insert the concealed round support tube into the nut post at the position of the power cord, and fix the two M5x6 tapered set screws with the nut post and the concealed decorative cover with an inner hexagonal wrench respectively.




step 3
Place the towel rack on the wall to be installed, and use a pencil to mark the position of the wall bracket screw and the decorative cover for concealed installation.




step 4
Use an 8MM drill bit to drill holes at the marked locations.



step 5
Knock the expansion tube into the drilled 8MM hole, and fix the installation base $\phi 18 \times 18$ on the wall with expansion screws.



step 6
Assemble the towel rack to the mounting base on the wall, screw the tapered set screw into the screw hole of the round tube support tube with an Allen wrench and tighten it. Screw the concealed circular support tube into the screw hole of the concealed decorative cover through the tapered set screw with an Allen wrench and tighten it, and fix the concealed decorative cover on the wall with cross recessed countersunk head self-tapping screws.



step 7
Connect the towel rail power cord to the junction box.

Towel Warmer Operating Instructions

1 Basic instructions:

1.1 Power supply specification: 220-240V~,50-60Hz

1.2 Setting temperature range: 30~60℃

1.3 Timing time: 1-8 hours


2 Digital tube display description:

2.1 Shutdown state: the digital tube does not display, as shown in the following figure:



2.2 Power on: Adjustable temperature range 30~60℃ , adjustable timing time 1-8 hours and normally open (ON)

As shown in the following figures:



3 Operating instructions:

3.1 Power on/off: Short press  to turn on the device to enter the startup state, short press again to enter the shutdown state.

3.2 Timing setting: Short press  to flash, step by 1 hour, set the time until 8 hours, short press  again to display the word ON (ON means open normally open state, heating has no time limit and is only affected by the set temperature). Press again  for a short time to return to 1 hour. After setting it for 3 seconds, it will enter the working state without operation, and the digital tube will stop flashing; when the heating time is over, the device will automatically shut down

3.3 Temperature setting: Short press the  button to flash, step by 5°C, set the temperature until it reaches 60°C, short

press  again to set the temperature back to 30°C. After setting, the digital tube stops flashing if it is not operated for 3 seconds and enters the working state.

4. Error display

4.1 When the temperature probe is abnormal, the digital tube displays the following figure:



Towel Rail Installation

- Read the instruction sheet carefully before installation.
- Installation should be completed by a professional electrician.
- Please dispose the package properly.

tools required



Screwdriver



Pencil



Spirit Level




Rubber Hammer




Tape Measure




Gloves



Perceuse électrique




	Tube rond tube de support	X 3
	Tube support circulaire monté en surface (avec encoche pour le passage des fils)	X 1
	Nouveau tube d'expansion	X 4
	Vis d'expansion	X 4
	Base de montage	X 4
	Vis à tête cylindrique Phillips	X 3
	Vis de réglage de la pointe du cône	X 5
	Clé Allen	X 1




étape 1

Veuillez confirmer le lieu d'installation avant de procéder à l'installation




étape 2


Fixer les trois tubes ronds de support aux poteaux d'écrou à l'arrière du porte-serviettes avec des vis à tête cylindrique M6*12. Mettre en place un tube support circulaire monté en surface avec un
Introduire l'encoche de passage du câble dans la colonne d'écrou à l'endroit où se trouve le câble d'alimentation, et fixer la vis de blocage M5x6 avec l'extrémité conique à l'aide d'une clé hexagonale intérieure.




étape 3
Placez le porte-serviettes sur le mur à installer et marquez l'emplacement des vis du support mural à l'aide d'un crayon.



étape 4
Utilisez une mèche de 8 mm pour percer les trous aux endroits marqués.



étape 5
Enfoncez le tube d'expansion dans le trou de 8 mm et fixez la base d'installation $\phi 18 \times 18$ sur le mur avec des vis d'expansion.








étape 6
Assembler le porte-serviettes à la base de montage sur le mur, visser la vis de pression conique dans le trou de vis du tube rond de support avec un tournevis.
une clé Allen et la serrer.

Towel Rail Installation

- Read the instruction sheet carefully before installation.
Installation should be completed by a professional electrician.
- Please dispose the package properly.

tools required



X 1


couvercle décoratif
dissimulé




X 1

Support rond dissimulé


	Tube rond tube de support	X 3
	Nouveau tube d'expansion	X 3
	Vis d'expansion	X 3
	Base de montage	X 3
	Vis à tête cylindrique Phillips	X 3
	Vis à tête fraisée cruciforme	X 2
	Vis de réglage de la pointe du cône	X 5
	Clé Allen	X 1



étape 1
Veuillez confirmer le lieu d'installation avant de
procéder à l'installation.




étape 2
Fixer les trois tubes ronds de support à l'écrou situé à l'arrière du porte-serviettes, à
l'endroit où le bouchon a été coupé, à l'aide de la vis à tête cylindrique Phillips M6*12.
Insérez le tube de support rond dissimulé dans le montant de l'écrou à l'emplacement
du cordon d'alimentation, et fixez les deux vis de réglage coniques M5x6 avec le
montant de l'écrou et le couvercle décoratif dissimulé à l'aide d'une clé hexagonale
intérieure, respectivement.




étape 3

Placez le porte-serviettes sur le mur à installer, et utilisez un crayon pour marquer la position de la vis du support mural et du couvercle décoratif pour une installation dissimulée.




étape 4

Utilisez une mèche de 8 mm pour percer les trous aux endroits marqués.




étape 5

Enfoncez le tube d'expansion dans le trou de 8 mm et fixez la base d'installation $\phi 18 \times 18$ sur le mur à l'aide de vis d'expansion.



étape 6

Assemblez le porte-serviettes à la base de montage sur le mur, vissez la vis de réglage conique dans le trou de vis du tube de support rond avec une clé Allen et serrez-la. Visser le tube de support circulaire dissimulé dans le trou de vis du couvercle décoratif dissimulé à travers la vis de réglage conique à l'aide d'une clé Allen et le serrer, puis fixer le couvercle décoratif dissimulé au mur à l'aide de vis autotaraudeuses à tête fraisée encastrée transversale.



étape 7

Branchez le cordon d'alimentation du sèche-serviettes sur le boîte de jonction.

Mode d'emploi du sèche-serviettes

1 Instructions de base :

1.1 Spécification de l'alimentation électrique : 220-240V~,50-60Hz

1.2 Plage de température de réglage : 30,--,60°C


1.3 Durée : 1 à 8 heures

2 Description de l'affichage numérique :

2.1 État d'arrêt : le tube numérique ne s'affiche pas, comme le montre la figure suivante :



2.2 Mise sous tension : Plage de température réglable 30,--,60°C , temps de temporisation réglable 1-8 heures et normalement ouvert (ON) Comme indiqué dans les figures suivantes :



3 Mode d'emploi :

3.1 Mise en marche/arrêt : Une brève pression  permet d'allumer l'appareil et d'entrer dans le système. les
démarrage état, court presse à nouveau
pour entrer les
état d'arrêt.

3.2 Réglage de la durée : Appui court  à l'éclair, au pas d'une heure, régler l'heure sur 8 heures, appuyer brièvement sur la touche  pour afficher le mot ON (ON signifie normalement ouvert),

Le chauffage n'a pas de limite de temps et n'est affecté que par la température de consigne.

température). Appuyer à nouveau  pendant un court instant pour revenir à 1 heure. Après l'avoir réglée pendant 3 secondes, elle passe en mode de fonctionnement.

L'appareil s'éteint automatiquement à la fin de la période de chauffage.

3.3 Réglage de la température : Appuyer brièvement sur le

 bouton pour faire clignoter, avancer de 5°C, régler la température jusqu'à ce qu'elle atteigne 60°C, appuyer brièvement sur le bouton pour faire clignoter la température.

presse  pour remettre la température à 30°C. Après le réglage, le tube numérique s'arrête de clignoter s'il n'est pas utilisé pendant 3 heures.

secondes et passe à l'état de travail.

4. Affichage des erreurs

4.1 Lorsque la sonde de température est anormale, le tube numérique affiche la figure suivante :

