



Two Function Concealed Shower Set Installation

INSTALLATION MANUAL


Tools You Will Need:




Adjustable wrench



Hex key (Allen)



Phillips Screwdriver




PTFE (Teflon) tape

Notes before installation:


1. Ensure all components are present.
2. Before installation, flush all supply lines and ensure an accessible shut-off valve is present.
3. Operating pressure: 140–860 kPa (20–125 psi) total, combined hot and cold.
4. Illustrations are representative and may differ slightly from the product supplied.
5. For extended absences, shut off the main water supply.
6. Flush all water lines before installation to remove debris.
7. If soldering near the valve, remove the cartridge and all rubber/plastic parts. Allow the valve body to cool completely, then reinstall the cartridge and seals.
8. Tighten the cartridge retaining nut to 11–13 N·m.




Valves are factory-tested. If field testing is required, it must be performed by a licensed plumber. For AIR tests, do not exceed 86 kPa (12.5 psi). For HYDROSTATIC tests, do not exceed the manufacturer's specified test pressure. Remove the cartridge before any test above normal line pressure and reinstall afterwards.




1. Confirm the valve location and fasten the pressure-balance valve to blocking.




2. Connect hot and cold inlets and the outlets; secure piping to framing.




3. Snap the protective cover onto the valve body (155 × 135 mm oval).




4. Cut the wall opening to suit the protective cover (≈ 5 mm clearance all around)




5. Remove the screw and take off the protective cover.




6. Install the escutcheon to the valve body and fasten to the wall. Install the handle and tighten the set screw.



7.01. Fasten the slide-bar holder to the wall with the tapping screw.
02. Tighten the hex set screw.



8. Install the outlet connector at the wall. Connect the hose to the outlet and to the hand shower.



9. Install the shower arm, flange, and showerhead. Apply PTFE (Teflon) tape to threaded joints clockwise and tighten.